Touch POS Terminal

(Simple Operating Manual)





Your touch POS terminal package is included with components as follows:





Touch POS Terminal









User's Manual

Optional accessories







MSR/Dallas Key

Customer display screen

Secondly display screen

Power ON/OFF





Power button is on the back of the LOGO

POWER ON: Connect the power cable correctly and press the power button. POWER OFF: Click shut down in OS, or press the power button to shut down.



To hide the power cable: 1.Remove rear cover 2.Place power cable


through the cable hole on the base

3.Install rear cover

I/O Description







1,24V DC IN 2,12V DC OUT 3.Cash Drawer 4.COM (RS232) 5.USB 6.LAN 7.VGA 8.Audio

9.HDD/SSD (Optional)

Adjust screen view angle

The description and picture here are for reference only.




Hold left and right sides and adjust view angle while terminal without MSR and iButton.



Hold top and bottom sides and adjust view angle while terminal with MSR and iButton.

For any alternation to the product information, no additional notification will be made. See specific items in the package box for details.

Install MSR and ibutton (Optional)









Remove interface cover

Connect MSR/ibutton port to host port


Install MSR/ibutton module to terminal and fix it screws

Install the 2nd Screen (Optional)











Remove the switch cover for the 2nd screen (unscrew the screws on the top of base, can remove it)

Place cables through the cable hole on the base and the top of base (original location of switch cover)

Intall the 2nd Screen (mind the cables) and the cover

Connect the cables

Replace HDD/SSD (Optional)













Open interface cover

Remove HDD/SSD when terminal is off

Replace HDD/SSD after releasing 2 screws on both sides

Mind HDD/SSD direction while installation