MINDEO

MD22xx barcode scanner quick guide

- A standard packing includes a scanner, a USB cable and a CD (or a user manual). P
- Accessories include a stand, a RS232 cable, a 5V adaptor and a PS/2 cable. Ē
- Use a piece of dry and soft cloth when cleaning the scanner. (B

Parts of the scanner




- ① LED
- Exit window
- ③ Trigger
- ④ Cable interface port
- (5) Release-hole of the cable
- 6 Beeper

Default value initialization and Firmware version list



Programming instruction and example



Assembling the stand (accessory)



Firmware version list

Example: to set Flow control to be XON/XOFF.

Installing the cable


- 1. Switch off the host:
- 2. Refer to the below pictures, connect the host with the scanner based on different cables;
- 3. Ensure that all connections are secure.
- 4. Switch on the host system. If installation is successful, the beeper will beep and LED will light.








RS232 cable



PS/2 cable

Removing the cable

- 1. Find the release-hole.
- Insert a thin wire into the hole and pull out the cable gently.



- 1. See the figure above, tighten the screws.
- 2. Bend the neck to the desired position for scanning.
- 3. Screw mounting: Screw one #10 wood screw into each screw-mount-hole until the base of the stand is secured.
- 4. Tape mounting: ①Peel the paper liner off one side of each piece of tape and place the sticky surface over each of the three rectangular tape holders. ②Peel the paper liner off the exposed sides of each piece of tape and press the stand on a flat surface until it is secure.

