


# Quick Start Guide


**iD4P**

**iD4S**




## Appearance and Components

### ■ Front View(eg.:iD4P)




### ■ Rear View



**⚠ Note: The views above are for your reference. Ports vary by your choice.**

### ■ Inside View




## Xiamen Hanin Electronic Technology Co.,Ltd.

ADD: 5F, 8#, Aide Airport Industrial Park, Huli District, Xiamen, China.


TEL:400-806-9290

WEB:www.idprt.com


## Packing List




Printer(eg:iD4P)



AC Adapter



Label Roll



Power Cord



CD




Quick Start Guide



USB Cable

## USB Connection

- 1.Connect the AC adapter to power receptacle.
- 2.Connect the power cord to AC adapter.
- 3.Connect the other end of power cord to the outlet.




Varies by regions


**⚠ Note: The packing materials are actually based on the order.**

## Loading the Ribbon


1. Pull and lift the cover. (eg:iD4P)




2. Pull the roll holders open and place the roll between them.




3. Press down the locking tab.



4. Pass the label through the label guides, then adjust guides to adapt to the label width.



5. Press the cover lock and close the cover slightly.



6. Press down the cover until it snaps closed.

