



NORDIC ID SAMPO S2 & NORDIC ID SAMPO S2 ONE-SERIES QUICK GUIDE

KURZANLEITUNG GUIDE RAPIDE GUÍA RAPIDA
GUIDA RAPIDA GUÍA RAPIDO SNABBGUIDE PIKAOPAS
QUICK GUIDE HURTIUGUIDE HRAÐLEIÐBEININGAR
SNELLE START RÖVID KEZELÉSI ÚTMUTATÓ מדריך מהיר למשתמש
دليل سريع КРАТКОЕ РУКОВОДСТВО 快速指南 クイックガイド 퀵가이드

nordic^{id}

CONNECTIONS

DE/	ANSCHLÜSSE
FR/	CONNECTIVITÉ
ES/	CONEXIONES
IT/	CONNESSIONI
PT/	CONEXÕES
SV/	ANSLUTNINGAR
FI/	YHTEYDET
DA/	TILSLUTNINGER
NO/	TILKOBLINGER
IS/	TENGINGAR
NL/	AANSLUITINGEN
HU/	CSATLAKOZÓK
HE/	חיבורים
AR/	التوصيل
RU/	ПОДКЛЮЧЕНИЕ ВНЕШНИХ УСТРОЙСТВ
ZH/	連接口
JA/	接続



DC 12-24V Ethernet GPIO USB host USB device External Antenna Ports

! Nordic ID Sampo S2
RF POWER 1W
DC 12-24V / 18W
PoE 802.3af / 12W

! Nordic ID Sampo S2 One-series
RF POWER 2W (ERP)
DC 12-24V / 18W
PoE 802.3af / 12W


MOUNTING OPTIONS

DE/	MONTAGEMÖGLICHKEITEN
FR/	OPTIONS DE MONTAGE
ES/	OPCIONES DE MONTAJE
IT/	OPZIONI DI MONTAGGIO
PT/	OPÇÕES DE MONTAGEM
SV/	MONTERINGSALTERNATIV
FI/	ASENNUSVAIHTOEHTOJA
DA/	MONTERINGSMULIGHEDER
NO/	MONTERINGSALTERNATIVER
IS/	VALKOSTIR Í UPPSETNINGU
NL/	MONTAGE MOGELIJKHEDEN
HU/	FELSZERELÉSI LEHETŐSÉGEK
HE/	אפשרויות התקנה
AR/	خيارات التثبيت
RU/	ВАРИАНТЫ МОНТАЖА
ZH/	安装方法
JA/	取り付けオプション



POWER & COMMUNICATION OPTIONS

DE/	SPANNUNGS- & KOMMUNIKATIONSOPTIONEN
FR/	OPTIONS D'ALIMENTATION ET DE COMMUNICATION
ES/	POTENCIA Y OPCIONES DE COMUNICACIÓN
IT/	OPZIONI DI ALIMENTAZIONE E COMUNICAZIONE
PT/	OPÇÕES DE ENERGIA E COMUNICAÇÃO
SV/	STRÖMFÖRSÖRJNING OCH KOMMUNIKATION
FI/	VIRTALÄHTEET JA TIEDONSIIRTO
DA/	POWER & KOMMUNIKATION MULIGHEDER
NO/	STRØM OG KOMMUNIKASJON ALTERNATIVER
IS/	VALKOSTIR SPENNUFÆÐINGAR OG SAMSKITPA
NL/	POWER & COMMUNICATIE-OPTIES
HU/	TÁPELLÁTÁS ÉS KOMMUNIKÁCIÓS LEHETŐSÉGEK
HE/	אפשרויות חשמל ותקשורת
AR/	التوصيل بالطاقة وخيارات الاتصال
RU/	ПОДКЛЮЧЕНИЕ К ИСТОЧНИКАМ ПИТАНИЯ И ВНЕШНИМ УСТРОЙСТВАМ
ZH/	电源和通讯选项
JA/	電力・通信オプション








COMMUNICATION VIA USB

DE/	KOMMUNIKATION ÜBER USB
FR/	COMMUNICATION VIA USB
ES/	COMUNICACIÓN A TRAVÉS DE USB
IT/	COMUNICAZIONE TRAMITE USB
PT/	COMUNICAÇÃO VIA USB
SV/	KOMMUNIKATON VIA USB
FI/	TIEDONSIIRTO USB:N KAUTTA
DA/	KOMMUNIKATION VIA USB
NO/	KOMMUNIKASJON VIA USB
IS/	SAMSKIPTI Í GEGNUM USB
NL/	COMMUNICATIE VIA USB
HU/	USB KOMMUNIKÁCIÓ
HE/	תקשורת באמצעות USB
AR/	الاتصال عبر ال USB
RU/	ПОДКЛЮЧЕНИЕ ЧЕРЕЗ USB-ПОРТ
ZH/	USB 通信连接
JA/	USB経由での通信



LEDS & BUZZER

DE/	LED'S & SUMMER
FR/	LEDS ET BUZZER
ES/	LED Y ZUMBADOR
IT/	LED E BUZZER
PT/	LEDS E CAMPAINHA
SV/	LED OCH LJUDSIGNAL
FI/	LEDIT JA ÄÄNISIGNAALI
DA/	LEDS & BUZZER
NO/	LED OG LYDSIGNAL
IS/	LJÓSDÍÓÐUR OG BJALLA
NL/	LEDS & ZOEMER
HU/	HANG- ÉS FÉNYJELZÉSEK
HE/	חיווי קולי וחזותי
AR/	المصابيح والجرس
RU/	СВЕТОДИОДНЫЕ ИНДИКАТОРЫ И ЗУММЕР
ZH/	信号灯和蜂鸣器
JA/	LEDとブザー



TAPPING SENSOR TRIGGER (CONFIGURATION OPTIONS)

DE/	BERÜHRUNGSSENSOR (KONFIGURATIONS-MÖGLICHKEITEN)
FR/	CAPTEUR DE TACTILE (OPTIONS DE CONFIGURATION)
ES/	TOCANDO DISPARADOR DEL SENSOR (OPCIONES DE CONFIGURACIÓN)
IT/	PULSANTE (OPZIONI DI CONFIGURAZIONE)
PT/	SENSOR DE TOQUE (OPÇÕES DE CONFIGURAÇÃO)
SV/	UTLÖSARE AV TRYCKSENSOR (KONFIGURATIONSMÖGLIGHETER)
FI/	KOSKETUSTUNNISTIN (ESIMERKKEJÄ ASETUKSISTA)
DA/	TRYK SENSOR UDLØSER (KONFIGURATIONSMULIGHEDER)
NO/	TRYKSENSOR UTLØSER (KONFIGURASJONSALTERNATIVER)
IS/	ÁSLÁTTARNEMI VIRKJA (VAL Í UPPSETNINGU)
NL/	TAPSENSOR (CONFIGURATIE-OPTIES)
HU/	ÉRINTŐ KAPCSOLÓK (KONFIGURÁCIÓS BEÁLLÍTÁSOK)
HE/	לחצו לחצן מגע מואר (להגדרות)
AR/	التصت الاستشعار الزناد (خيارات التكوين)
RU/	СЕНСОРНАЯ ПАНЕЛЬ (ПАРАМЕТРЫ КОНФИГУРАЦИИ)
ZH/	点击传感器触发 (配置选项)
JA/	タッピングセンサーのトリガー (設定オプション)



- A** "RFID inactive"

RFID OFF
- B** "RFID enabled - Send notification"

RFID ON
- C** "RFID enabled - Scan Tag"

RFID READ
- D** "RFID enabled - Inventory"

RFID READ



Limited warranty: 2 years / Begrenzte Garantie: 2 Jahre
Garantie limitée: 2 ans / Garantía limitada: 2 años
Garanzia limitata: 2 anni / Garantia limitada: 2 anos
Begränsad garanti: 2 år / Rajoitettu takuu: 2 vuotta
Begrænset garanti: 2 år / Begrenset garanti: 2 år
Takmörkuð ábyrgð: 2 ár / Beperkte garantie: 2 jaar
Korlátozott jótállás: 2 év / אחריות מוגבלת: שנתיים
ضمانة محدودة لمدة سنتين / Ограниченная гарантия: 2 года
有限保修期: 2年 / 限定保証: 2年 / 보증기간: 2년

Repair centers / Reparaturzentren / Centres de réparation
/ Centros de reparación / centri di riparazione / Os centros
de reparação / Reparationscenter / Huoltopiste / Reparation
centre / Reparasjonscenter / Viðgerðarmiðstöð / Reparatie
centra / Szerviz információk / מרכזי שירות / مراكز الاصلاح / 維修
中心 / 修理センター:

www.nordicid.com/en/home/support/repair-service



www.nordicid.com/downloads/

HEADQUARTERS
support@nordicid.com
phone: +358 2 7277 790

DEUTSCHSPRACHIGE LÄNDER
support@nordicid.de
Tel: +49 5206 70 84 70